



- | | | |
|-------------------------------------|--|-------------------------------------|
| 1. Wheel speed sensor (Right-front) | 6. Data link connector | 11. Proportioning valve |
| 2. Stop lamp switch | 7. Wheel speed sensor (Left-rear) | 12. Wheel speed sensor (Left-front) |
| 3. ABS control module | 8. "ABS" warning lamp | 13. ABS hydraulic unit |
| 4. Wheel speed sensor (Right-rear) | 9. ABS pump motor relay | |
| 5. DIAG-2 connector | 10. ABS fail-safe relay (Solenoid valve relay) | |

