



1. Ignition switch
2. ABS control module
3. Left-front wheel speed sensor
4. Right-front wheel speed sensor
5. Left-rear wheel speed sensor
6. Right-rear wheel speed sensor

